

### Drill Chucks & Keys

Adapts arbor with 1/2"-20 thread to hole saw with 5/8"-18 thread



Chuck Capacity	Thread Size	Chuck Part No.	Key Part No.	Key Holder No.
0 - 1/4"	3/8" - 24	21077	30000	
0 - 1/4"	3/8" - 24	21019A	30202	
0 - 3/8"	1/2" - 20	21002	30011	14273
0 - 3/8"	3/8" - 24	21085	30231	14273
1/16" - 3/8"	1/2" - 20	21131	30002	
1/16" - 3/8"	3/8" - 24	21133	30002	14273
1/16" - 3/8" <sup>1</sup>	3/8" - 24	65562		
5/64" - 1/2"	3/8" - 24	21132	30429	
5/64" - 1/2"	1/2" - 20	21137	30011	14273

<sup>1</sup>Keyless Chuck  
Keyed chucks include key

### Wire Brushes



Part Number	Type	Size	Wire Size	Maximum RPM
224	Hollow Center	1 X 1"	.008	22,000
225	Flared End	1 1/2"	.020	22,000
226	Solid Wire Filled	1 X 1"	.020	22,000
227	Solid Wire Filled	3/4 X 1"	.020	22,000
228	Solid Wire Filled	1/2 X 1"	.020	25,000
231	Knot Type	1 X 1 1/8"	.014	22,000
232	Knot Type	1 X 1 1/8"	.020	22,000

Shank size: 1/4" Sold in packages of 5

### Drill Midget Chucks



Part Number	Collet Size		Spindle Thread
	in.	mm	
2418	1/16	1.6	1/4 - 20
2419	1/8	3.2	1/4 - 20
2420	3/16	4.8	1/4 - 20

### Drill Arbors

Mounts in Drill Chuck to provide threaded output spindle



Part Number	Thread Size	Shank Size	Body Size
49	3/8" - 16	1/4"	1/2"
49A	5/8" - 11	1/4"	5/8"

### Remote Exhaust Kit



Part Number	For Use On
3301	1400 series pistol grip drills
3303	Z-handle drills
3302	1 series straight drills

### Quick Change Chuck

**Part No. 2352**

Adapts 3/8"-24 threaded spindles to 1/4" hex quick change



### Support Handle

**Part No. 2355**

For use on ES, 2L, 3P series drills



### Comfort Grips

For use on ES, 2L, 3P series drills



SAFETY Precaution: Read and follow all safety and operating instructions.

**WARNING:** Face & eye protection must be worn while operating power tools, per ANSI B186.1

