



MODEL: LU8016ALM

Item No.	Part No.	Part Name	Item No.	Part No.	Part Name
1	22200101	CAP	34	HS0412B	HEX.SOC.HD.BOLT
2	OR3825R	O-RING	35	HS0518BW	HEX.SOC.HD.BOLT+SW
3	19000301	CYLINDER PRESS RING	36	19103601	NOSE
4	OR3420R	O-RING	37	10703801	SET PLATE
5	19000501	CYLINDER	38	22203802	MAGAZINE
6	OR2420R	O-RING	39	11305501	SHAFT
7	OR1830R	O-RING	40A	16604002A	STAPLE GUIDE UNIT
8A-1	19100801A	DRIVER ASSEMBLY	41	19004801	SET PLATE
8A-2	19100803A	DRIVER ASSEMBLY	42	19104501	PUSHER
9	11502001	BUMPER	43	20704601	SPRING
10	20701001	COLLAR	44	US0408B	UM. HD. BOLT
11	OR1610R	O-RING	45A	10405201A	END CORE ASM.
12	20701201	VALVE	46	22200301	BRACKET
13	20701301	VALVE PLUNGER	47	HS0512B	HEX. SOC. HD. BOLT
14	OR1215R	O-RING	48	HS0406B	HEX. SOC. HD. BOLT
15	OR0610R	O-RING	55	10205301	SET PLATE
16	20701601	COLLAR	56	FH0406B1	FLAT. HD. BOLT
17	OR1310R	O-RING	59	20705901	PLUNGER
18	OR3515H	O-RING	60	OR2510H	O-RING
19	20701901	VALVE PLUNGER	61	OR3510H	O-RING
20	OR1110R	O-RING	62	20706201	SLEEVE
21	OR0810R	O-RING	63	16309101	SPRING
22	OR0310R	O-RING	64	20706401	PLUNGER
23	OR1710R	O-RING	65	20706501	PLUNGER CAP
25	20702501	PLUNGER CAP	66	20706601	SPRING
26	22202601	TRIGGER	67	20706701	SLEEVE
27	20905501	SHAFT	68	22206801	PILOT NUT
28	OR1919H	O-RING	69	22206901	PILOT VALVE
29	22202901	BODY	69-1	OR0510R	O-RING
30	19103001	JOINT GUIDE	70	22204901	SET BLOCK
31	22203101	EXHAUST DIFFUSER	71	FH0412B	FLAT. HD. BOLT
32	22203201	COVER	72	LNO400N	LOCK NUT
33	12106401	AIR PLUG	73	20707201	SPRING