




SD216COM SD2750COM



Wespro Pneumatic Tools

REVERSIBLE SCREWDRIVER





No.	Description	Order Code	Q'ty	No.	Description	Order Code	Q'ty
1	Pistol Housing	225954	1	29-1	First Plant Gear [SD2750COM]	225876	4
2	O Ring (5x1)	225835	1	30	First Gear Cage [SD216COM]	225972	1
3	Blank Cap	225836	1	30-1	First Gear Cage [SD2750COM]	228799	1
4	O Ring (3.5x2)	225837	1	31	Second Main Gear [SD216COM]	225974	1
5	Valve O-Ring (3x1.5)	225838	1	31-1	Second Main Gear [SD2750COM]	228800	1
6	Valve Pin	225839	1	32	Second Plant Gear [SD216COM]	225975	4
7	Cone Spring (0.45)	225840	1	32-1	Second Plant Gear [SD2750COM]	225876	4
8	Valve Bushing	225841	1	33	Second Gear Cage [SD216COM]	228801	1
8-1	O Ring (8x1)	225842	2	33-1	Second Gear Cage [SD2750COM]	225878	1
9	Trigger	225843	1	34	Internal Gear	228802	1
10	Cap	225844	2	35	Ball Bearing (688ZZ)	141851	2
11	O Ring (P10)	225955	2	36	Clutch Housing	225979	1
12	Screw Cap	225845	2	36-1	Washer	228803	1
13	Spring	225957	1	37	Anvil (6.35Hex)	225917	1
14	Valve O-Ring	225958	1	38	C Ring	225918	1
15	Reverse Valve	225959	1	39	Ball (1/8")	228804	3
16	Set Screw (M2.6x12) And Washer	225849	1	40	Washer	225920	1
17	Reverse Lever	225960	1	41	Torque Spring (2.8)[SD216COM]	228805	1
18	Ball Bearing (624ZZ)	112052	1	41-1	Torque Spring (3.2)[SD2750COM]	228806	1
19	End Plate	225961	1	42	Regulation Washer	228807	1
19-1	Roll Pin (1.6x4.5)	228793	1	43	Torque Ring	228808	1
20	Cylinder	225962	1	44	C Ring	225926	1
21	Rotor [SD2750COM]	228794	1	45	Ball (2.38)	225927	1
22	Rotor [SD216COM]	228795	1	45-1	Bushing	228944	1
23	Rotor Blade	225966	6	46	Bit Slide Sleeve	228945	1
24	Front Plate	225968	1	47	Spring (0.6)	225928	1
24-1	Roll Pin (2.5x3.5)	228796	1	48	C Ring	225933	1
25	Ball Bearing (688ZZ)	141851	1	49	Pistol Cover	225983	1
26	C Ring [SD2750COM]	225872	1	50	O Ring (P10)	225955	1
27	Connect [SD216COM]	225873	1	51	Air Inlet Bushing (NPT)	225936	1
28	First Main Gear [SD216COM]	228797	1	52	Filter	225937	1
28-1	Internal Gear [SD2750COM]	228798	1	53	Silencer	225984	1
29	First Plant Gear [SD216COM]	225970	4				

How to operate Direction



How to replace the bit



How to adjust the Torque

